



**DOLPHIN
PROPULSION SYSTEM
SERVICE MANUAL**

TABLE OF CONTENTS

INTRODUCTION	1-1		
OPERATION	2-1		
Normal Motoring Operation	2-1	Normal Operating Temperature ranges .	2-1
Normal Charging Operation	2-1		
MAINTENANCE	3-1		
Service safety	3-1	Explanation of Each Field	
Handling Electrostatic Discharge		on Screen in Charging Mode	3-39
(ESD) Sensitive Parts	3-1	STATUS Field	3-40
NOTICE	3-1	Fault Field	3-41
Scheduled Maintenance Philosophy	3-1	Veh Inf Field	3-42
Corrective Maintenance Philosophy	3-2	Vac Peak Field	3-43
Corrective Maintenance	3-2	Iac Peak Field	3-43
General Description	3-2	VBat Field	3-43
Power Control Unit	3-2	IBat Field	3-43
Motor	3-2	Vac * Iac Field	3-43
Motor Encoder	3-2	User Defined Field	3-43
Motor Encoder Cable	3-2	12V Bias Field	3-43
Required Tools and Test Equipment	3-2	Dolphin Unit Temp Field	3-43
Diagnostic Computer	3-2	Address User <UNIT VEH> Field	3-43
Diagnostic Software	3-2	Charge Mode Field	3-43
Computer Cabling	3-2	AC Relay Field	3-43
Test Equipment	3-2	Time Seconds Field	3-43
Dolphin Diagnostics	3-6	Motor Temp Field	3-44
Dolphin Propulsion System		Fault Description Field	3-44
Diagnostics	3-11	Driver Controls	3-45
Troubleshooting with Diagnostic		Driver Controls Diagnostics	3-45
Computer Procedure	3-28	Cooling System	3-45
Explanation of Motoring Mode		Cooling System Diagnostics	3-45
Display Fields	3-34	PCU Removal and Replacement	3-45
STATUS Field	3-35	PCU Removal Procedure	3-45
Fault Field	3-36	Coolant Removal Procedure	3-47
Veh Inf Field	3-37	PCU Replacement Procedure	3-47
Velocity (RPM) Field	3-38	Motor Removal and Replacement	3-47
Velocity (MPH) Field	3-38	Motor Removal Procedure	3-47
Battery V Field	3-38	Motor Replacement Procedure	3-47
Command Direction Field	3-38	Motor Encoder Cable	
MOTOR Direction Field	3-38	Removal and Replacement	3-47
12V Bias Field	3-38	Motor Encoder Cable Removal	
User Defined Field	3-38	Procedure	3-47
Battery Current Field	3-38	Motor Encoder Cable Replacement	
Power In Field	3-38	Procedure	3-49
Current Command % Field	3-38	Motor Encoder Removal and	
Address User <UNIT VEH> Field	3-38	Replacement	3-49
Dolphin Unit Temp Field	3-38	Motor Encoder Removal	
Time Seconds Field	3-38	Procedure	3-49
Motor Temp Field	3-39	Motor Encoder Replacement	
Fault Description Field	3-39	Procedure	3-49
WARRANTY INFORMATION	4-1	Re-shipment Failed Modules	
Preparation for Re-shipment	4-4	for Repair	3-50
PCU Shipping Procedure	4-4	Motor Shipping Procedure	4-5

LIST OF ILLUSTRATIONS

<u>Figure</u>	<u>Title</u>	<u>Page</u>	<u>Figure</u>	<u>Title</u>	<u>Page</u>
Figure 1-1.	Dolphin Propulsion System and Interfaces	1-1	Figure 3-15.	Fault Indicator Remains On Diagnostic Procedure (Part 2 of 2)	3-22
Figure 1-2.	Dolphin Power Control Unit (PCU)	1-2	Figure 3-16.	No Ready Indicator Diagnostic Procedure	3-23
Figure 1-3.	Dolphin AC Induction Traction Motor	1-3	Figure 3-17.	Integral Charger Diagnostic Procedure	3-24
Figure 3-1.	Electrostatic Discharge Sensitive Parts Label	3-1	Figure 3-18.	PCU 12 VDC Auxiliary Charger Diagnostic Procedure	3-25
Figure 3-2.	Dolphin Propulsion System Block Diagram (Sheet 1 of 2)	3-4	Figure 3-19.	Motor Diagnostic Procedure	3-26
Figure 3-3.	Miles Per Charge Has Degraded Diagnostic Procedure	3-11	Figure 3-20.	Three Phase AC Output Cable Pin-Out	3-27
Figure 3-4.	Vehicle Powers Down Unexpectedly Diagnostic Procedure	3-12	Figure 3-21.	DOS Prompt	3-28
Figure 3-5.	Temperature Problems Diagnostic Procedure (Part 1 of 2)	3-13	Figure 3-22.	Computer Diagnostics Executable Program	3-28
Figure 3-6.	Temperature Problems Diagnostic Procedure (Part 2 of 2)	3-14	Figure 3-23.	Computer Diagnostic Program Opening Screen	3-29
Figure 3-7.	Motor Encoder Diagnostic Procedure	3-15	Figure 3-24.	Serial Communication Set-up Screen	3-29
Figure 3-8.	Motor Encoder Cable Pin-Out	3-16	Figure 3-25.	Diagnostic Display Initiate	3-30
Figure 3-9.	Motor Encoder Cable Diagnostic Procedure	3-16	Figure 3-26.	Motoring Mode Diagnostics Display	3-30
Figure 3-10.	No Indicator Lights Diagnostic Procedure (Part 1 of 2)	3-17	Figure 3-27.	Charge Mode Diagnostics Display	3-31
Figure 3-11.	No Indicator Lights Diagnostic Procedure (Part 2 of 2)	3-18	Figure 3-28.	Computer Diagnostic Opening Screen	3-31
Figure 3-12.	Signal Connector J4 Pin-Out	3-19	Figure 3-29.	Computer Diagnostics Exit Screen	3-32
Figure 3-13.	12 VDC Power Location	3-20	Figure 3-30.	PCU Connections	3-45
Figure 3-14.	Fault Indicator Remains On Diagnostic Procedure (Part 1 of 2)	3-21	Figure 3-31.	PCU Connections	3-45
			Figure 3-32.	PCU Mounting	3-46
			Figure 3-33.	Motor Encoder and Cable Assembly	3-48
			Figure 3-34.	Motor Encoder Assembly	3-51
			Figure 4-1.	PCU Packing Diagram	4-4
			Figure 4-2.	Motor Packing Diagram	4-5
			Figure 4-3.	Motor Packing Diagram	4-6

LIST OF TABLES

<u>Table</u>	<u>Title</u>	<u>Page</u>	<u>Table</u>	<u>Title</u>	<u>Page</u>
Table 3-1.	Scheduled Maintenance	3-3	Table 3-3.	Dolphin System Fault/Status Definitions	3-33
Table 3-2.	Diagnosis of Dolphin Propulsion System	3-6	Table 3-4.	Part Identification and Information	3-50

SECTION I

INTRODUCTION

This manual covers the Dolphin propulsion system (Figure 1-1) which consists of a power control unit (PCU) (Figure 1-2) and an ac induction traction motor (Figure 1-3). The Dolphin system possesses important features such as performance, efficiency, safety, low maintenance and ease of conversion, in addition to the environmental considerations of zero emission transportation. The electronic matching of the PCU and motor as well as the off-throttle regeneration and regenerative braking all contribute to the high efficiency of the Dolphin propulsion system. The Dolphin propulsion system includes safety features such as, built-in interlocks as well as circuitry to monitor battery isolation for high voltage protection. The dolphin propulsion system itself requires no regular maintenance. In addition, the Dolphin propulsion system reduces brake wear (due to the off-throttle regeneration) and also extends the life of the accessory battery by keeping a slow trickle charge on the battery. This propulsion system is adaptable to a variety of internal combustion engine automobiles using the existing cooling and +12 Vdc electrical systems as well as the transmission. The conversion would also require propulsion battery packs and a 110/220 Vac chassis assembly for charging.




Figure 1-1. Dolphin Propulsion System and Interfaces




Figure 1-2. Dolphin Power Control Unit (PCU)





Figure 1-3. Dolphin AC Induction Traction Motor



SECTION II

OPERATION

NORMAL MOTORING OPERATION

Normal operating procedure is as follows:

1. Insert car key into start switch.
2. Turn key to on position.
3. Fault indicator appears for approximately 2 seconds and then turns off.
4. The ready indicator will then be lit.
5. Car is now ready for normal operation.

NORMAL CHARGING OPERATION

Normal charging procedure is as follows:

1. Turn main battery switch on.
2. Ensure start switch is in off position.
3. Insert 110/220 V ac single-phase line into charger receptacle.
4. Charger indicator blinks during charge cycle.
5. When charging is complete, charge indicator is continuously lit.
6. Disconnect 110/220 V ac single-phase line from charger receptacle.

NORMAL OPERATING TEMPERATURE RANGES

It is normal for the temperature gauge to fluctuate from minimum to maximum depending upon the load and ambient temperature conditions to which the Dolphin propulsion system is subjected. The Dolphin propulsion system is designed to operate in an environment where coolant temperature is maintained between -30 to $+65^{\circ}\text{C}$. The power control unit (PCU) shuts down when the temperature of its coldplate is greater than $+65^{\circ}\text{C}$.

SECTION III MAINTENANCE

SERVICE SAFETY

CAUTION: Before removing or installing any electrical unit or when a tool or equipment could easily come in contact with "live" exposed electrical terminals, disconnect the negative auxiliary battery cable to help prevent personal injury and/or damage to the vehicle or components. Unless instructed otherwise, the key switch and the main battery pack external on/off switch shall be in the "off" position.

HANDLING ELECTROSTATIC DISCHARGE (ESD) SENSITIVE PARTS

Many solid state electrical components can be damaged by electrostatic discharge (ESD). Some will display a label as shown in figure 3-1, but many will not.

NOTICE



Figure 3-1. Electrostatic Discharge Sensitive Parts Label

NOTICE: Before any servicing is performed on the Dolphin Propulsion system, proper ESD precautions should be taken. The following are some of the precautions that should be taken:

1. Use one hand to touch the chassis before proceeding. This will discharge any build up of static charge on your person.
2. Always wear an anti-static wrist strap that is attached to a secure ground when handling any component of the Dolphin propulsion system before they have been properly installed.
3. Do Not use a static strap when voltage levels higher than 50 volts are present.
4. Do not touch exposed electrical terminals on components or connectors with your finger or any tools.
5. Never jumper, ground or use test equipment probes on any components or connectors unless specified in diagnostics.
6. Do not remove the solid state component from its protective packaging until you are ready to install the part.

SCHEDULED MAINTENANCE PHILOSOPHY

The Dolphin propulsion system requires no scheduled maintenance, however, to maintain peak operating efficiency the coolant and interface cables should be checked regularly. These items interface with the Dolphin propulsion system and can directly degrade the system's efficiency. It is highly recommended that the scheduled maintenance for these items be followed (table 3-1).

CORRECTIVE MAINTENANCE PHILOSOPHY

The Dolphin propulsion system corrective maintenance procedures can be used to troubleshoot down to the field replaceable unit (FRU). The FRUs are the power control unit (PCU), traction control motor, motor encoder, motor encoder cable or other system within the vehicle (i.e. battery, cooling or +12 Vdc electrical system etc.). All FRU failures should be removed and replaced by a qualified technician. Fuses are serviceable on-site and do not require the removal of an FRU. The troubleshooting procedures are written for manual or computer-assisted troubleshooting, however it is strongly advised that a diagnostic computer be used for troubleshooting the Dolphin propulsion system. Figure 3-2 is the system electrical interface diagram.

CORRECTIVE MAINTENANCE

GENERAL DESCRIPTION

POWER CONTROL UNIT

The PCU integrates a three-phase ac power inverter, dc/dc converter and an integral charger into one main assembly. The PCU power inverter converts high voltage dc into three-phase ac power for the motor. The dc/dc converter provides a trickle charge for the +12 Vdc auxiliary battery. The integral charger is compatible with 110/220 Vac single phase 15 amp service.

MOTOR

The Dolphin propulsion system uses an ac induction traction motor with an environmentally sealed housing. The traction motor can be coupled to a standard transmission that is fixed in first or second gear. The traction motor is electronically matched (tuned) to the output of the power inverter of the power control unit (PCU), increasing the power transfer to the road.

MOTOR ENCODER

The motor encoder is located within the motor housing where it monitors the rotation of the motor spindle. The motor encoder translates the rotation of the motor spindle into electrical impulses and is relayed through the motor encoder cable to the PCU. The PCU then calculates the speed of the car from the electrical impulses.

MOTOR ENCODER CABLE

The motor encoder cable carries +5 volts, motor encoder signals and temperature signals. The +5 volt signal powers the motor encoder circuitry housed within the motor housing. The motor encoder signals relay motor speed information to the PCU. The temperature signal is a voltage between 0 and 5 volts that is analogous to the temperature of the motor.

REQUIRED TOOLS AND TEST EQUIPMENT

DIAGNOSTIC COMPUTER

The diagnostic computer is a 486 microprocessor-based PC computer (preferably a laptop style) that is compatible with the Hughes Power Systems diagnostic software. The diagnostic computer must also have the capability to communicate with the PCU via RS-232 or SAE J1850 serial interface.

DIAGNOSTIC SOFTWARE

The only software that shall be used to troubleshoot the Dolphin propulsion system is the diagnostic software written by Power Control Systems.

COMPUTER CABLING

- 9-pin RS-232 cable

TEST EQUIPMENT

- Digital Multi-meter, Beckman 310 or equivalent (Required)
- A 80486 class PC compatible computer loaded with Hughes Power Control Systems diagnostic software with a RS-232 cable. (Optional)

Table 3-1. Scheduled Maintenance

ITEM	SERVICE INTERVAL	RECOMMENDED ACTION
Coolant		
• Check Coolant Level	Every 2 Weeks	Top off with 50/50 ethylene glycol or water with a corrosion inhibitor
• Replace Coolant	Every 12 Months	Replace with 50/50 ethylene glycol or water with a corrosion inhibitor
Cables		
• Check Cable Connectors	Every Week	Visual inspection of cable connectors
• Check for Cable Chaffing	Every 2 Months	Visual inspection of cables




Figure 3-2. Dolphin Propulsion System Block Diagram (Sheet 1 of 2)




Figure 3-2. Dolphin Propulsion System Block Diagram (Sheet 2 of 2)

DOLPHIN DIAGNOSTICS

Table 3-2. Diagnosis of Dolphin Propulsion System

PROBLEM	POSSIBLE CAUSE	CORRECTION
Start-up Fault – No Indicator Lights (Reference no indicator lights diagnostic proce- dure (part 1 of 2) Figure 3-10)	<ol style="list-style-type: none"> 1. Cables to PCU are loose or disconnected. 2. US Electricar auxiliary power system fault. 3. 12 Vdc line fuse blown. 4. PCU fault. 5. Indicator lights may be burned out. 	<ol style="list-style-type: none"> 1. Disconnect and reconnect all cables to PCU. 2. Refer to US Electricar auxiliary power system diagnostic procedure. 3. Replace blown fuse. 4. Refer to computer diagnostic program. Replace PCU if necessary. 5. Refer to US Electricar indicator diagnostics procedure.
Start-up Fault – Fault Indicator Remains On (Reference fault indicator remains on diagnostic pro- cedure (part 1 of 2) Figure 3-14)	<ol style="list-style-type: none"> 1. Cables to PCU are loose or disconnected. 2. Main battery pack external on/off switch is off. 3. Accelerator pedal not in fully off position. 4. Pre-charge fuse blown. 5. Low auxiliary battery. 6. Fuse inside PCU integral charger is blown. 7. US Electricar auxiliary power system fault. 8. PCU fault. 	<ol style="list-style-type: none"> 1. Disconnect and reconnect all cables to PCU. 2. Turn switch to on position. 3. Reposition accelerator pedal to off position. 4. Refer to US Electricar auxiliary power system diagnostic procedure. 5. Check auxiliary battery voltage with volt meter or diagnostic computer; charge battery if necessary. 6. Check fuse, replace if necessary. 7. Refer to US Electricar auxiliary power system diagnostic procedure. 8. Refer to diagnostic computer. Replace PCU if necessary.
Start-up Fault – No Ready Indicator (Reference no ready indi- cator diagnostic procedure Figure 3-16)	<ol style="list-style-type: none"> 1. Cables to PCU are loose or disconnected. 2. US Electricar auxiliary power system fault. 3. Accelerator is not fully off. 4. Main power relay may not be engaging. 5. PCU fault. 	<ol style="list-style-type: none"> 1. Disconnect and reconnect all cables to PCU. 2. Refer to US Electricar auxiliary power system diagnostic procedure. 3. Reposition accelerator to off position. 4. Refer to US Electricar main power diagnostic procedure. 5. Refer to computer diagnostic program. Replace PCU if necessary.

Table 3-2. Diagnosis of Dolphin Propulsion System (CONT.)

PROBLEM	POSSIBLE CAUSE	CORRECTION
<p>Motoring Fault – Car Will Not Move</p>	<ol style="list-style-type: none"> 1. Cables to PCU are loose or disconnected. 2. Main power relay may not be engaging. 3. Motor interlock is open or motor fault. 4. PCU fault. 5. Transmission fault. 	<ol style="list-style-type: none"> 1. Disconnect and reconnect all cables to PCU. 2. Refer to US Electricar main power diagnostic procedure. 3. Refer to the motor diagnostic procedure Figure 3-19. 4. Refer to computer diagnostic program. Refer to PCU remove and replacement procedure if PCU replacement is necessary. 5. Refer to US Electricar transmission diagnostic procedure.
<p>Motoring Fault – Miles Per Charge Has Degraded</p>	<ol style="list-style-type: none"> 1. Low air pressure in tires. 2. Main batteries pack not fully charged. 3. State of charge meter fault. 4. High impedance in the power circuit causing voltage drop. 5. Integral charger within PCU is not fully charging the batteries. 6. Main batteries fault. 7. Motor fault. 	<ol style="list-style-type: none"> 1. Inflate tires to proper pressure level. 2. Charge main battery pack. 3. Refer to US Electricar indicator diagnostic procedure. 4. Refer to US Electricar main power diagnostic procedure. 5. Refer to integral charger diagnostic procedure Figure 3-17. 6. Refer to US Electricar main power diagnostic procedure. 7. Refer to motor diagnostics procedure Figure 3-19.
<p>Motoring Fault – Vehicle Slips Into Charge Mode While Motoring</p>	<ol style="list-style-type: none"> 1. PCU fault. 	<ol style="list-style-type: none"> 1. Replace PCU. Refer to PCU removal and replacement procedure.
<p>Motoring Fault – Vehicle Indicators Will Not Turn Off When Key Is In Off Position To shut-off the vehicle in this condition you must:</p> <ol style="list-style-type: none"> 1. Turn-off main battery switch or, 2. Open one of the PCU interlocks. 	<ol style="list-style-type: none"> 1. Fused main power relay. 2. Bad ignition switch. 3. PCU fault 	<ol style="list-style-type: none"> 1. Refer to US Electricar main power diagnostic procedure. 2. Refer to US Electricar auxiliary power system diagnostics procedure. 3. Replace PCU. Refer to PCU removal and replacement procedure.

Table 3-2. Diagnosis of Dolphin Propulsion System (CONT.)

PROBLEM	POSSIBLE CAUSE	CORRECTION
Motoring Fault – Vehicle Powers Down Un- expectedly	<ol style="list-style-type: none"> 1. Loose connector. 2. Thermal shutdown. 3. Low auxiliary battery. 4. Motor fault. 5. PCU fault. 	<ol style="list-style-type: none"> 1. Disconnect and reconnect all PCU cables. 2. Refer to the temperature problems diagnostic procedure (part 1 of 2) Figure 3-5. 3. Check auxiliary battery voltage with volt meter or diagnostic computer; charge battery if necessary. 4. Refer to the motor diagnostic procedure Figure 3-19. 5. Refer to the computer diagnostic procedure. Replace PCU if necessary.
Motoring Fault – Temperature Problems	<ol style="list-style-type: none"> 1. Low coolant. 2. Water pump fault. 3. Fan fault. 4. PCU fault. 	<ol style="list-style-type: none"> 1. Refill coolant reservoir with proper coolant mixture. 2. Refer to US Electricar water pump diagnostic procedure. 3. Refer to US Electricar fan diagnostic procedure. 4. Refer to the temperature problems diagnostic procedure (part 1 of 2) Figure 3-5. Replace PCU if necessary.
Motoring Fault – Unusual Noise During Mo- toring	<ol style="list-style-type: none"> 1. Motor noise – <ol style="list-style-type: none"> a. Loose motor mounting bolts. b. Motor fault. 2. PCU noise – <ol style="list-style-type: none"> a. Loose PCU mounting bolts. b. PCU fault. 3. Other car noise 	<ol style="list-style-type: none"> 1. Repair as necessary. <ol style="list-style-type: none"> a. Tighten motor mounting bolts. See motor replacement procedure for specifics. b. Refer to motor removal and replacement procedure. 2. Repair as necessary. <ol style="list-style-type: none"> a. Tighten PCU mounting bolts. See PCU replacement procedure for specifics. b. Refer to PCU removal and replacement procedure. 3. Refer to US Electricar noise diagnostic procedure.

Table 3-2. Diagnosis of Dolphin Propulsion System (CONT.)

PROBLEM	POSSIBLE CAUSE	CORRECTION
<p>Motoring Fault – Vehicle movements Are Not Normal</p>	<ol style="list-style-type: none"> 1. Cables to PCU are loose or disconnected. 2. Main battery pack not fully charged. 3. Main battery pack fault. 4. Integral charger is not fully charging main battery pack. 5. High impedance in the power circuit causing voltage drop. 6. Motor encoder fault. 7. Motor fault. 8. PCU fault 	<ol style="list-style-type: none"> 1. Disconnect and reconnect all cables to PCU. 2. Charge main battery pack. 3. Refer to US Electricar main power diagnostic procedure. 4. Refer to integral charger diagnostic procedure Figure 3-17. 5. Refer to US Electricar main power diagnostic procedure. 6. Refer to motor encoder diagnostic procedure Figure 3-7. 7. Refer to motor diagnostic procedure Figure 3-19. 8. Refer to computer diagnostic procedure. Replace PCU if necessary.
<p>Charging Fault – Charge Indicator Never Lights</p>	<ol style="list-style-type: none"> 1. Cables to PCU are loose or disconnected. 2. Indicator is burned out. 3. Fuse within integral charger is blown. 4. GFI switch has been tripped. 5. PCU fault. 	<ol style="list-style-type: none"> 1. Disconnect and reconnect all cables to PCU. 2. Refer to US Electricar indicator diagnostic procedure. 3. Replace fuse. 4. Reset GFI switch. 5. Replace PCU.
<p>Charging Fault – Charge Indicator Does Not Blink During Charge Mode or Fault Light On and Charge Light Blinks</p>	<ol style="list-style-type: none"> 1. Cables to PCU are loose or disconnected. 2. Indicator is burned out. 3. Start key is in ON position. 4. Pre-charge fuse blown. 5. GFI switch has been tripped. 6. PCU fault. 	<ol style="list-style-type: none"> 1. Disconnect and reconnect all cables to PCU. 2. Refer to US Electricar indicator diagnostic procedure. 3. Turn start key to OFF position. 4. Refer to US Electricar auxiliary power system diagnostic procedure. 5. Reset GFI switch. 6. Replace PCU.

Table 3-2. Diagnosis of Dolphin Propulsion System (CONT.)

PROBLEM	POSSIBLE CAUSE	CORRECTION
Charging Fault – Main Battery Pack Not Fully Charging (Reference integral charger diagnostic procedure Figure 3-17)	<ol style="list-style-type: none"> 1. Charge cable from power source is not fully connected. 2. Loose connectors to PCU. 3. High impedance in the power circuit causing voltage drop. 4. Integral charger is not producing enough current. 5. Main battery pack fault. 	<ol style="list-style-type: none"> 1. Disconnect and reconnect charge cable plug. 2. Disconnect and reconnect all connectors to PCU. 3. Refer to US Electricar main power diagnostic procedure. 4. Use diagnostic computer or current probe to measure output current of the integral charger. Replace PCU if necessary. Refer to PCU removal and replacement procedure. 5. Refer to US Electricar main power diagnostic procedure.
Charging Fault – 12 Volt Auxiliary Battery Loses Its Charge (Reference PCU 12 vdc auxiliary charger diagnostic procedure Figure 3-18)	<ol style="list-style-type: none"> 1. Cable connection between auxiliary battery and PCU is loose. 2. Bad power cable between PCU and auxiliary battery. 3. 12 volt auxiliary battery fault. 4. DC/DC converter is faulty. 	<ol style="list-style-type: none"> 1. Tighten connections at PCU and auxiliary battery. 2. Refer to US Electricar auxiliary power system diagnostic procedure. Replace cable if necessary. 3. Refer to US Electricar auxiliary power system diagnostic procedure. Replace battery if necessary. 4. Refer to PCU 12 vdc auxiliary charger diagnostics procedure Figure 3-18. Replace PCU if necessary.

DOLPHIN PROPULSION SYSTEM DIAGNOSTICS




Figure 3-3. Miles Per Charge Has Degraded Diagnostic Procedure




Figure 3-4. Vehicle Powers Down Unexpectedly Diagnostic Procedure




Figure 3-5. Temperature Problems Diagnostic Procedure (Part 1 of 2)




Figure 3-6. Temperature Problems Diagnostic Procedure (Part 2 of 2)




Figure 3-7. Motor Encoder Diagnostic Procedure




Figure 3-8. Motor Encoder Cable Pin-Out




Figure 3-9. Motor Encoder Cable Diagnostic Procedure




Figure 3-10. No Indicator Lights Diagnostic Procedure (Part 1 of 2)




Figure 3-11. No Indicator Lights Diagnostic Procedure (Part 2 of 2)




Figure 3-12. Signal Connector J4 Pin-Out




Figure 3-13. 12 VDC Power Location




Figure 3-14. Fault Indicator Remains On Diagnostic Procedure (Part 1 of 2)




Figure 3-15. Fault Indicator Remains On Diagnostic Procedure (Part 2 of 2)




Figure 3-16. No Ready Indicator Diagnostic Procedure




Figure 3-17. Integral Charger Diagnostic Procedure




Figure 3-20. Three Phase AC Output Cable Pin-Out

TROUBLESHOOTING WITH DIAGNOSTIC COMPUTER PROCEDURE

- Note that the term drive A is only a reference. Depending on the set-up of the computer used substitute the drive and directory (if applicable) of the location where the Dolphin diagnostic program is located. Furthermore, the procedure will assume that there is a pointing device such as a mouse or trackball, keyboard equivalents will be given in parenthesis. To select an item the pointing device must be clicked once. The keyboard equivalents are usually two key combination that are selected simultaneously ie. Alt-D requires the user to press the ALTERNATE key and the D key simultaneously. Full explanation of each field in the motoring or charging display begins on page .

The diagnostic procedure is as follows:

1. Plug-in the RS-232 cable into the RS-232 port of the Dolphin PCU and computer.
2. Initiate and run the diagnostic program on the computer.
 - a. Put the Dolphin test software disk into the A drive of the laptop.
 - b. Log-onto drive A. The screen should look similar to Figure 3-21.
 - c. Initiate the diagnostic program by typing DOLCOM. The screen should look similar to Figure 3-22.
 - d. The initial diagnostic screen will look similar to Figure 3-23.
 - e. Move the pointing device to the DATA menu and selected it (Alt-D). The screen should look similar to Figure 3-25.
 - f. Select DISPLAY (D) and the screen should look similar to Figure 3-26 (motoring mode) or Figure 3-27 (charge mode). This is the diagnostics display.
3. Read the fault description and DSP status words and match the bits to the bits listed in table 3-3 or refer to the specific troubleshooting diagram for use with the laptop.
4. To exit the diagnostics program press 0 to return to the initial screen. See Figure 3-28.
5. To exit the program entirely, move the pointing device to the FILE menu and select it (ALT-F). The select EXIT (X). See Figure 3-29.



Figure 3-21. DOS Prompt



Figure 3-22. Computer Diagnostics Executable Program




Figure 3-23. Computer Diagnostic Program Opening Screen




Figure 3-24. Serial Communication Set-up Screen




Figure 3-25. Diagnostic Display Initiate

DATA RAM EDIT SCREEN		MOTORING MODE	
STATUS	->	0 = Fault	31 = Accell
Fault	->	1 = Status	32 = Accell1
Veh Inf	->	2 = an0 (VBatt)	33 = Vregen
Velocity (RPM)	->	3 = an1 (IBatt)	34 = id
Velocity (MPH)	->	4 = an2 (Acc 0)	35 = iq
Battery V	->	5 = an3 (Acc 1)	48 = batI
Command Direction	->	->	6 = an4 (Acc 2)
MOTOR Direction	->	7 = an5 (Brake)	64 = Vel Cmd
12V Bias	->	8 = an6 (Regen)	132 = Anminflt
User Defined	->	9 = an7 (Isolation)	133 = Anmaxflt
Battery Current	->	10 = an8 (P12V)	134 = Anmin Offset
Power In	->	11 = an9 (Line Vac)	135 = isov
Current Command %	->	12 = anA (Line Iac)	137 = Vmin
Address User	->	14 = iop	145 = fwdlim
		15 = Regen Gain	147 = batonmin
		19 = position	151 = Slip < Base
Cold Plate Temp	->	22 = Fault Delay	182 = Regen Drive
		24 = vell	183 = Regen Low
		28 = BatI Offset	184 = Regen Two
Time Seconds	->	29 = vmul	206 = Slip
0: Exit		30 = Brake	224 = SOC Out
1: Dolphin Unit Memory Read		Enter Choice ->	
2: Vehicle Interface Memory Read			

Figure 3-26. Motoring Mode Diagnostics Display

DEFINITIONS

		RAM ADD 0				
		3	2	1	0	
4						
X		X	X	X	X	
			Correlation	Brake	Accelerator	
	Charge Port	Key On	TBD	TBD	TBD	
		RAM ADD 1				

DEFINITIONS

		3	2	1	0
	220/110 VAC	Park (1)	Internal	Stable (1)	Enable (1)
	Vmode (1)				
	Stable (1)				
	Charge Port				

EXPLANATION OF MOTORING MODE DISPLAY FIELDS

Turn Key to ON position, the "DATA RAM EDIT SCREEN MOTORING MODE" screen will show up with data filled in as follow;

*** DATA RAM EDIT SCREEN		MOTORING MODE ***	
STATUS	->	0000 1000 1011 0110	0 = Fault
Fault	->	0000 0000 0000 0101	1 = Status
Veh Inf	->	1000 0000 0000 1011	2 = an0 (VBatt)
Velocity (RPM)	->	0.00	3 = an1 (IBatt)
Velocity (MPH)	->	0.00	4 = an2 (Acc 0)
Battery V	->	335.40	5 = an3 (Acc 1)
Command Direction	->	DRIVE	6 = an4 (Acc 2)
MOTOR Direction	->	FORWARD	7 = an5 (Brake)
12V Bias	->	11.32	8 = an6 (Regen)
User Defined	->		9 = an7 (Isolation)
Battery Current	->		10 = an8 (P12V)
Power In	->	0.00	11 = an9 (Line Vac)
Current Command	->	0.00	12 = anA (Line Iac)
Address User	->		14 = iop 145 = fwdlim
		15 = Regen Gain	147 = batonmin
		19 = position	151 = Slip < Base
Dolphin Unit Temp	->	35	22 = Fault Delay
		24 = vell	182 = Regen Drive
Time Seconds	->	1.5	183 = Regen Low
0: Exit		29 = vmul	28 = BatI Offset
1: Dolphin Unit Memory Read		30 = Brake	206 = Slip
2: Vehicle Interface Memory Read		Enter Choice ->	224 = SOC Out
Accel Correl			31 = Accell
			32 = Accell1
			33 = Vregen
			34 = id
			35 = iq
			48 = batI
			52 = Power
			64 = Vel Cmd
			132 = Anminflt
			133 = Anmaxflt
			134 = Anmin Offset
			135 = isov
			137 = Vmin

VEH INF FIELD

The *Veh Inf* field consists of 16 bits in combination of 0s or 1s. Each 0 or 1 represents different vehicle interface status. The left most bit represents the most significant bit (MSB); the right most bit represents the least significant bit (LSB). The following table explains each status bit:

Bit F (bit 15)	-	Dolphin Unit fault status
	1	Dolphin unit has fault
	0	Dolphin unit is fine
Bit E (bit 14)	-	Overheat status
	1	Dolphin unit or/and motor is overheated
	0	Dolphin unit or/and motor is not overheated
Bit D (bit 13)	-	Not implemented yet
Bit C (bit 12)	-	Not implemented yet
Bit B (bit 11)	-	Not implemented yet
Bit A (bit 10)	-	Not implemented yet
Bit 9	-	Charge port status
	1	Charge port is being used
	0	Charge port is not being used
Bit 8	-	Not implemented yet
Bit 7	-	Park Brake Status
	1	Parking brake is on
	0	Parking brake is off
Bit 6	-	Brake High Switch Status (If installed)
	1	High limit brake switch on by pressing on the brake
	0	No high limit brake switch on
Bit 5	-	Brake Low Switch Status (If installed)
	1	Low limit brake switch on by pressing on the brake
	0	No low limit brake switch on
Bit 4	-	*PRNDLP Switch Status
	1	PRNDLP switch on
	0	PRNDLP switch off
Bit 3	-	*PRNDLC Switch Status
	1	PRNDLC switch on
	0	PRNDLC switch off
Bit 2	-	*PRNDLB Switch Status
	1	PRNDLB switch on
	0	PRNDLB switch off
Bit 1	-	*PRNDLA Switch Status
	1	PRNDLA switch on
	0	PRNDLA switch off
Bit 0	-	Key on Status
	1	Key is ON position
	0	Key is OFF

* Combination of PRNDLP, PRNDLC, PRNDLB, and PRNDLA switches determines the transmission selection

VELOCITY (RPM) FIELD

The *Velocity (RPM)* field represents the motor speed in revolutions per minutes while the vehicle is in motion.

VELOCITY (MPH) FIELD

The *Velocity (MPH)* field represents the vehicle speed in miles per hour while the vehicle is in motion.

BATTERY V FIELD

The *Battery V* field represents the battery voltage in Volts.

COMMAND DIRECTION FIELD

The *Command Direction* field represents the transmission selection.

MOTOR DIRECTION FIELD

The *MOTOR Direction* field represents the state of the motor direction.

12V BIAS FIELD

The *12V Bias* field represents the 12V bias supply voltage in Volts.

USER DEFINED FIELD

The *User Defined* field prints out the value of the Dolphin Unit processor memory location that user specified. Following is how to read the memory location:

1. Type 1 or 2 (**DO NOT HIT RETURN**)

1 - To read the Dolphin Unit controller memory location (Memory location and its usage is already on the screen, also refer to RAM description table)

2 - To read the vehicle interface controller memory location (None on screen, refer to RAM description table)

2. Type memory location address and return field

3. The value will show up in the *User Defined*

BATTERY CURRENT FIELD

The *Battery Current* field represents the battery current in Ampere.

POWER IN FIELD

The *Power In* field represents the power going into the motor while the accelerator pedal is depressed and the vehicle is moving.

CURRENT COMMAND % FIELD

The *Current Command %* field represents current command in use.

ADDRESS USER <UNIT|VEH> FIELD

The *Address User <UNIT|VEH>* field prints out the memory address that the user specified. Either *UNIT* or *VEH* prints out depends on the user selection.

DOLPHIN UNIT TEMP FIELD

The *Dolphin Unit Temp* field represents the temperature of the Dolphin Unit in Celsius.

TIME SECONDS FIELD

The *Time Seconds* field represents how long the communication between the PC and the Dolphin Unit been up. This field does not updates unless communication link is connected, therefore, if this field is not updating, then the communication link is not connected.

MOTOR TEMP FIELD

The *Motor Temp* field is a hidden field. To read the motor temperature:

1. Type **1 (DO NOT HIT RETURN)**
2. Type **238** and **RETURN**
3. The *Motor Temp* field shows up with the motor temperature in Celsius line after the Dolphin Unit Temp

To hide the *Motor Temp* field:

1. Type **1 (DO NOT HIT RETURN)**
2. Type **any memory address** and **RETURN**
3. The *Motor Temp* field will hide

FAULT DESCRIPTION FIELD

In the very last line, all the fault description prints out, if any fault occurs. In the example screen above, the Accel and Correl faults shows.

EXPLANATION OF EACH FIELD ON SCREEN IN CHARGING MODE

Plug in the **INDUCTIVE CHARGE Paddle** to the charge port, or connect the AC plug to the power outlet, the following screen will show up:

DATA RAM EDIT SCREEN CHARGE MODE			
STATUS	->	0001 1100 1001 0010	0 = Fault
FAULT	->	0000 0000 0000 0000	1 = Status
Veh Inf	->	0000 0000 0000 0000	2 = Battery V
			3 = Battery I
Vac Peak	->	155.56	9 = Isolation
Iac Peak	->	3.02	11 = Line Vac
VBat	->	329.24	12 = Line Iac
IBat	->	-1.05	14 = IOP(dsp in)
Vac * Iac	->	234.90	15 = Regen Gain
User Defined	->		22 = Delay
P12V	->	11.45	28 = BatI offset
Dolphin Unit Temp	->	38	29 = vmul
			48 = BatI
Address User	->		52 = Power
			54 = Chrg Scale
			55 = vacmax
Charge Mode	->	NORMAL	56 = iref 176 = chrseImx
AC Relay	->	CLOSED	58 = iaemax
Time Seconds	->	3.2	135 = IsoV
0: Exit		138 = Bat Off Min	147 = Bat On Min
1: Dolphin Unit Memory Read			160 = Vchrgslope
2: Vehicle Interface Read		Enter Choice ->	161 = Vchrgoff
			162 = Vchrgstart
			163 = Vmulmax
			164 = Vchrgmx
			165 = IREF Offset
			166 = VAC min off
			167 = Bat min On
			168 = Max Current
			169 = VAC Min
			170 = VBATMx LtcHOff
			171 = IAC Min LtcHOff
			173 = Trickle Ref
			174 = 120VAC Ref
			175 = 220VAC Ref
			177 = Vmode Delay
			178 = Imode Delay

STATUS FIELD

The *STATUS* field consists of 16 bits in combination of 0s or 1s. Each 0 or 1 represents different status of vehicle. The left most bit represents the most significant bit (MSB); the right most bit represents the least significant bit (LSB). The following table explains each status bit:

Bit F (bit 15)	–	Not implemented yet
Bit E (bit 14)	–	Test (Used in testing Dolphin Unit)
	1	Test mode
	0	Regular motoring mode
Bit D (bit 13)	–	Charge Complete Status
	1	Charge complete
	0	Charge in process
Bit C (bit 12)	–	Charge Mode
	1	Charge mode
	0	Motoring mode
Bit B (bit 11)	–	Main Relay Status
	1	Main Relay Closed
	0	Main Relay Opened
Bit A (bit 10)	–	AC Relay Status
	1	AC Relay Closed
	0	AC Relay Opened
Bit 9	–	Not implemented yet
Bit 8	–	Not implemented
Bit 7	–	PreCharge Relay Status
	1	PreCharge Relay Closed
	0	PreCharge Relay Opened
Bit 6	–	Not implemented yet
Bit 5	–	Not implemented yet
Bit 4	–	NORMAL Charge Mode Status
	1	Normal charge mode
	0	Trickle charge mode
Bit 3	–	220/110 VAC Selection Status
	1	220 Selected
	0	110 Selected
Bit 2	–	Not implemented yet
Bit 1	–	Dolphin system status
	1	Stable
	0	Not stable (Vehicle will not move)
Bit 0	–	Charge Port Selection Status
	1	Charge port is being used
	0	Charge port is not being used

FAULT FIELD

The *Fault* field consists of 16 bits in combination of 0s or 1s. Each 0 or 1 represents different fault status of vehicle. The left most bit represents the most significant bit (MSB); the right most bit represents the least significant bit (LSB). The following table explains each status bit:

Bit F (bit 15)	-	Not implemented yet
Bit E (bit 14)	-	Isolation fault status
	1	Isolation fault exist
	0	No isolation fault
Bit D (bit 13)	-	Battery High fault status
	1	Battery voltage is too high (higher than 370 Volts)
	0	No battery high fault
Bit C (bit 12)	-	Battery Low fault status
	1	Battery voltage is too low (lower than 270 Volts)
	0	No battery low fault
Bit B (bit 11)	-	IGBT fault status
	1	IGBT fault exist
	0	No IGBT fault
Bit A (bit 10)	-	P12V fault
	1	12 volts bias supply is too low (lower than 10 Volts)
	0	12 volts bias supply is fine
Bit 9	-	Power Down Status bit
	1	Power down sequence has been activated in the Dolphin Unit
	0	No power down sequence activated
Bit 8	-	Not implemented yet
Bit 7	-	AC Voltage Low Status
	1	AC in voltage is low
	0	AC in voltage is O.K.
Bit 6	-	Overheat
	1	Dolphin Unit or/and Motor is overheated
	0	No overheat condition
Bit 5	-	Interlock fault status
	1	Interlock fault exist (interlock is opened)
	0	No interlock fault (interlock is closed)
Bit 4	-	Charge Port status
	1	Charge port is being utilized
	0	Charge port is not being used
Bit 3	-	Key ON status
	1	Key is ON position
	0	Key is OFF
Bit 2	-	Not implemented yet
Bit 1	-	Not implemented yet
Bit 0	-	Not implemented yet

VEH INF FIELD

The *Veh Inf* field consists of 16 bits in combination of 0s or 1s. Each 0 or 1 represents different vehicle interface status. The left most bit represents the most significant bit (MSB); the right most bit represents the least significant bit (LSB). The following table explains each status bit:

Bit F (bit 15)	-	Dolphin Unit fault status
	1	Dolphin unit has fault
	0	Dolphin unit is fine
Bit E (bit 14)	-	Overheat status
	1	Dolphin unit or/and motor is overheated
	0	Dolphin unit or/and motor is not overheated
Bit D (bit 13)	-	Not implemented yet
Bit C (bit 12)	-	Not implemented yet
Bit B (bit 11)	-	Not implemented yet
Bit A (bit 10)	-	Not implemented yet
Bit 9	-	Charge port status
	1	Charge port is being used
	0	Charge port is not being used
Bit 8	-	Not implemented yet
Bit 7	-	Park Brake Status
	1	Parking brake is on
	0	Parking brake is off
Bit 6	-	Brake High Switch Status (If installed)
	1	High limit brake switch on by pressing on the brake
	0	No high limit brake switch on
Bit 5	-	Brake Low Switch Status (If installed)
	1	Low limit brake switch on by pressing on the brake
	0	No low limit brake switch on
Bit 4	-	*PRNDLP Switch Status
	1	PRNDLP switch on
	0	PRNDLP switch off
Bit 3	-	*PRNDLC Switch Status
	1	PRNDLC switch on
	0	PRNDLC switch off
Bit 2	-	*PRNDLB Switch Status
	1	PRNDLB switch on
	0	PRNDLB switch off
Bit 1	-	*PRNDLA Switch Status
	1	PRNDLA switch on
	0	PRNDLA switch off
Bit 0	-	Key on Status
	1	Key is ON position
	0	Key is OFF

* Combination of PRNDLP, PRNDLC, PRNDLB, and PRNDLA switches determines the transmission selection

VAC PEAK FIELD

The *Vac Peak* field represents the peak voltage of the AC line in.

IAC PEAK FIELD

The *Iac Peak* field represents the peak current of the AC line in.

VBAT FIELD

The *VBat* field represents the battery voltage in Volts.

IBAT FIELD

The *IBat* field represents the battery current in Ampere.

VAC * IAC FIELD

The *Vac * Iac* field represents the calculated charging power.

USER DEFINED FIELD

The *User Defined* field prints out the value of the Dolphin Unit processor memory location that user specified. Following is how to read the memory location:

1. Type 1 or 2 (**DO NOT HIT RETURN**)

1 – To read the Dolphin Unit controller memory location (Memory location and its usage is already on the screen, also refer to RAM description table)

2 – To read the vehicle interface controller memory location (None on screen, refer to RAM description table)

2. Type memory location address and return

3. The value will show up in the *User Defined* field

12V BIAS FIELD

The *12V Bias* field represents the 12V bias supply voltage in Volts.

DOLPHIN UNIT TEMP FIELD

The *Dolphin Unit Temp* field represents the temperature of the Dolphin Unit in Celsius.

ADDRESS USER <UNIT|VEH> FIELD

The *Address User <UNIT|VEH>* field prints out the memory address that the user specified. Either *UNIT* or *VEH* prints out depends on the user selection.

CHARGE MODE FIELD

The *Charge Mode* field represents the charge mode, either NORMAL mode or TRICKLE mode.

AC RELAY FIELD

The *AC Relay* field represents the status of the AC Relay, either CLOSED or OPEN.

TIME SECONDS FIELD

The *Time Seconds* field represents how long the communication between the PC and the Dolphin Unit been up. This field does not updates unless communication link is connected, therefore, if this field is not updating, then the communication link is not connected.

MOTOR TEMP FIELD

The *Motor Temp* field is a hidden field. To read the motor temperature

1. Type 1 (DO NOT HIT RETURN)
2. Type 238 and RETURN
3. The *Motor Temp* field shows up with the motor temperature in Celsius line after the Dolphin Unit Temp

To hide the *Motor Temp* field,

1. Type 1 (DO NOT HIT RETURN)
2. Type any memory address and RETURN
3. The *Motor Temp* field will hide

FAULT DESCRIPTION FIELD

In the very last line, all the fault description prints out, if any fault occurs.

DRIVER CONTROLS

COOLING SYSTEM

DRIVER CONTROLS DIAGNOSTICS

COOLING SYSTEM DIAGNOSTICS

See drive controls section of the US Electricar manual.

See cooling system section of the US Electricar manual.

PCU REMOVAL AND REPLACEMENT

PCU REMOVAL PROCEDURE

Figures 3-30, 3-31, and 3-32



Important

- Turn the main battery switch to the off position



Remove or Disconnect

1. 12 volt positive auxiliary cable from auxiliary battery.
2. 12 volt auxiliary ground cable (1).



Remove or Disconnect

3. 12 volt auxiliary battery cable (3).

4. J6 (2).
5. J2 (7).
6. J1 (9).
7. J5 (5).
8. J4 (8).
9. Coolant hoses (4,6).
10. Six nuts or bolts (depending upon the configuration of the mounting bracket).



Install or Connect

11. Coolant caps to hoses.
12. Coolant caps to inlet/outlet.



Remove or Disconnect

13. PCU.




Figure 3-30. PCU Connections




Figure 3-31. PCU Connections




Figure 3-32. PCU Mounting

COOLANT REMOVAL PROCEDURE

1. Move PCU to an appropriate location for coolant disposal.



Remove or Disconnect

2. Coolant caps.
3. Coolant.

PCU REPLACEMENT PROCEDURE

Figures 3-30, 3-31, and 3-32



Important

- Turn the main battery switch to the off position



Remove or Disconnect

1. 12 volt positive auxiliary cable from auxiliary battery.



Install or Connect

2. Inverter on the bracket.



Tighten

- Six mounting nuts/bolts to 32 Nm (24 lb-ft.).

3. Mounting nuts or bolts (10).



Remove or Disconnect

4. Coolant caps from PCU.
5. Coolant caps from coolant hose (if applicable).



Install or Connect

6. Coolant hoses (4, 6).
7. High voltage cable to J2 (7).
8. Signal cable to J4 (8).
9. 3 phase output cable to J1 (9).
10. Motor encoder cable to J5 (5).
11. Integral charge input cable to J6 (2).
12. 12 volt auxiliary battery positive cable (3).
13. 12 volt auxiliary battery ground cable (1).
14. 12 volt positive auxiliary cable to auxiliary battery.

MOTOR REMOVAL AND REPLACEMENT

MOTOR REMOVAL PROCEDURE



Remove or Disconnect

Refer to US Electricar motor removal procedure.

MOTOR REPLACEMENT PROCEDURE



Install or Connect

Refer to US Electricar motor replacement procedure.

MOTOR ENCODER CABLE REMOVAL AND REPLACEMENT

MOTOR ENCODER CABLE REMOVAL PROCEDURE

Figure 3-33



Important

- CARE SHOULD BE TAKEN TO NOT DAMAGE THE GASKET BETWEEN THE motor ENCODER LID AND MOTOR.



Disassemble

1. Motor encoder lid (6) from motor (1).
 - a. Eight mounting bolts (10).




Inspect

2. Gasket, replace if required.



Remove or Disconnect

3. Motor encoder connector (5) from motor encoder (3).
4. Thermistor (4).
5. Grommet (7) from encoder lid cutout.
6. Motor encoder cable (9) and connector (5) through cutout of motor encoder lid (6).



- 1 MOTOR
- 2 MOTOR ENCODER HOUSING
- 3 MOTOR ENCODER
- 4 THERMISTOR
- 5 MOTOR ENCODER CONNECTOR
- 6 MOTOR ENCODER LID
- 7 GROMMET
- 8 STRAIN RELIEF
- 9 MOTOR ENCODER CABLE
- 10 BOLTS (8)

Figure 3-33. Motor Encoder and Cable Assembly

MOTOR ENCODER CABLE REPLACEMENT PROCEDURE



Assemble

1. Motor encoder cable (9) and connector through grommet (7).
2. Motor encoder cable (9) and connector through cutout of encoder lid.



Install or Connect

3. Grommet (7) in encoder lid cutout.
4. Motor encoder cable (9) to motor encoder (3).
5. RTV (Ultra Black 598 RTV silicone or equivalent) into area between grommet (7) and motor encoder cable (9).



Important

- Be sure to use enough RTV to seal the gap between the grommet and motor encoder cable.
- Allow Sufficient time for RTV to cure.



Assemble

6. Motor encoder lid (6) to motor (1).
7. Strain relief onto mounting bolt (10).



Tighten

8. Eight mounting bolts (10) in a star pattern.

MOTOR ENCODER REMOVAL AND REPLACEMENT

MOTOR ENCODER REMOVAL PROCEDURE

Figure 3-33 and 3-34



Important

- CARE SHOULD BE TAKEN TO NOT DAMAGE THE GASKET BETWEEN THE MOTOR ENCODER LID AND MOTOR.



Disassemble

1. Motor encoder lid (6) from motor (1).
 - a. Eight mounting bolts (10).



Inspect

2. Gasket, replace if required.



Remove or Disconnect

3. Motor encoder connector (5) from motor encoder (3).



Disassemble

4. Motor encoder mounting bolts (11).



Remove or Disconnect

5. Motor encoder (3).

MOTOR ENCODER REPLACEMENT PROCEDURE



Clean

- Inside of motor encoder housing (2).



Remove or Disconnect

1. Cardboard protector from new motor encoder.



Assemble

2. Motor encoder (3) onto shaft.



Important

- Be sure to add Loctite to motor encoder mounting bolts (11).
- Partially tighten motor encoder mounting bolts (11).

3. Motor encoder (3) with motor encoder mounting bolts (11).
4. Center motor encoder (3) around shaft.

 **Tighten**

- Motor encoder mounting bolts (11) down.
- Adjustment screw with motor encoder wheel adjustment tool (12) in a clockwise direction finger tight.

 **Remove or Disconnect**

5. Remove motor encoder adjustment tool (12).

 **Important**

- Push alignment notch (15) in a clockwise direction with tweezers until bottom alignment dot (14) aligns with top alignment dots (13).
- Spin motor shaft to ensure that motor encoder wheel does not rub against Motor encoder housing.

 **Assemble**

6. Motor encoder lid (6) to motor (1).
7. Strain relief (8) onto mounting bolt (10).

 **Tighten**

8. Eight mounting bolts (10) in a star pattern.

Table 3-4. Part Identification and Information

NAME	MANUFACTURE'S PART NUMBER
PCU	A04601AA0
Motor Assembly	A04731AA0
Motor Encoder Cable (W14)	A4706AA0
Optical Encoder Module (basic motor only)	HEDT-9100 F00
11.0MM Opt Rad Code Wheel (basic motor only)	HEDS-5120F13
Grommet	MS35489-8
Motor Encoder Lid Gasket	A04705FX0
Motor Assembly	A04731AA0-1
Motor Encoder Cable (W14)	A4706AA0-1
Optical Encoder Module (-1 motor only)	QEDS-5922
Grommet	MS35489-8
Motor Encoder Lid Gasket	A04705FX0

RE-SHIPPING FAILED MODULES FOR REPAIR

See warranty information and shipping instructions in section IV.




Figure 3-34. Motor Encoder Assembly

Dolphin™

Field Event Report (FER)



POWER CONTROL SYSTEMS



Note: A completed FER form, with a valid Return Authorization MUST accompany any item sent back to PCS for repair, replacement, credit, or other service.

Call 1(800) 482-6644 for Telephone Service Assistance and Return Authorization.

Return Initiator
 Authorization: _____ Name: _____ Phone: _____

Driver/Owner Contact: _____ Phone: _____

Vehicle Description: _____ Identification #: _____

Odometer Mileage: _____ Location: _____

Part Name: _____ Part #: _____ Serial #: _____

Briefly describe the event / incident / problem. (What happened or didn't happen?)

What was happening just before the event occurred? (For example, driving up hill at 35 mph, or vehicle at battery charger overnight)

Any other comments?

SECTION IV


WARRANTY INFORMATION

FER Form Instructions

Please follow these instructions completely to speed service

- Return Authorization:** Call the PCS service number (800) 482-6644 for telephone assistance before filling out the form. We may be able to solve your problem over the phone. If we are not able to solve your problem, you will need to have a valid Return Authorization to receive prompt service.
- Initiator:** Please enter your name and a phone number where you can be reached during normal business hours.
- Driver / Owner Contact:** Please enter the name of the driver or owner contact who may be able to provide additional detail about the event in case we need that information.
- Vehicle Description:** Please enter the make and model of the vehicle, e.g., Geo Prizm.
- Identification #:** Please enter the Vehicle Identification number – found under the windshield on the driver's side.
- Odometer Mileage:** Please enter the mileage from the vehicle's odometer at the time of the event.
- Location:** Where did the event occur? City and state.
- Part Name:** What's the name of the suspected part? (e.g., Power Control Unit)
- Part #:** Please enter the part number of the suspect unit from the nameplate.
- Serial #:** Enter the serial number from the nameplate.
- "Briefly describe the event . . ."** What happened or didn't happen that caused you or the driver to think there was a problem? Please include as much detail as possible.
- "What was happening just before the event occurred?"** Please describe the situation that led up to the event. What was the vehicle doing? Provide as much detail as possible.
- "Any other comments?"** This is your opportunity to provide us with any other comments you would like to offer about the event, the Dolphin system, our service or anything you would like to say to PCS.

DE/PCS PROPRIETARY



cedure

ARY

