


S10 TEST PACK


26 OLD 12V HAWKERS

Ground fault troubleshooting

A Ground Fault is unwanted resistance between the pack string and chassis ground.



If the highest voltage to truck chassis is measured near the center of the pack, here then you have ground faults at both the high(+312V) and low(pack fuse) sides of the pack string



NOTE: SOME CIRCUITS OMITTED FOR CLARITY