

IMPORTANT NOTICE! PLEASE READ CAREFULLY



2003 RL550/RL800 Operating Manual Addendum

In the 2003 Owner's Operating Manual it indicates that a text message, 'Ready-Keep Charging' will appear on the LCD screen of the manual controller when the Power Pack is fully charged and ready for use. This typically occurs in approximately 24 hours, depending on state of charge when connected to the RoboMower.

Please be aware that in some circumstances, the 'Ready-Keep Charging' message may not appear in this time frame, and may in fact not appear for a number of hours later. The message, 'Charging', will continue to display. **However, at the 24-26 hour time frame the Power Pack is fully charged and ready to use even if the 'Ready-Keep Charging' message does not display.**

The message of 'Ready-Keep Charging' is dependent upon a number of factors in the charge process, but has little impact from the current voltage level of the Power Pack. A variety of issues can delay the display of the message, such as ambient temperature and voltage output from your home receptacle. In any event, after approximately 24 hours of charging in the RoboMower, the Power Pack is fully charged and ready to use.

In addition, as a reminder, always keep the RoboMower connected to the charger when not in operation. The charging system is designed not to overcharge the Power Pack and will keep it at a 'float' voltage for optimum performance when needed. In off-season storage, fully charge the Power Pack and remove it from the RoboMower. Store it in an area that does not fall below freezing temperature. When ready to be used the following season, again fully charge the Power Pack and then begin mowing. This will insure proper life and service of your Power Pack.